



**USE IT**



**CLEAN IT**



**USE IT AGAIN**

**DISASSEMBLE**



Remove filters (discard if blocked).



Remove exhalation valve cover



Remove harness



Remove diaphragm

**CLEAN**



Clean mask body with soapy water



Clean exhalation valve cover



Clean diaphragm



Dry all components

**REASSEMBLE**



Replace diaphragm



Replace harness



Replace exhalation valve cover



Replace filters (new pair if required).

**WATCH THE VIDEO HERE**



[www.presstocheck.com](http://www.presstocheck.com)  
[www.jspsafety.com](http://www.jspsafety.com)  
[sales@jspsafety.com](mailto:sales@jspsafety.com)

Issued: 02/20 Copyright ©2020. JSP Ltd. All Rights Reserved